

OPERATING INSTRUCTIONS

WARNING LIGHT - SMART SANDWICH

FEATURES

5 Flash patterns

LI-battery 703040

72 hours battery life

360 degree horizontal angle, 180 degree vertical angle

AC-adapter and cigg plug 12-24V DC



INSTRUCTIONS

Test the battery state: Tap on the ON/OFF button.

Red x 4 times = 75%>

Red x 3 times = 50%>

Red x 2 times = 25%>

Red x 1 time = Low battery. Charge!

Tap the ON/OFF button to change flash pattern. A green diode will tell you which pattern that is on.

Green x1 = Pattern no. 1, Green x2 = Pattern no.2 and so on.

Asynchronous flash mode and synchronized flash mode can be switched by pressing the ON/OFF button twice quickly.

All flares in the same frequency can be turned off at the same time by pressing the ON/OFF button in any single flare three seconds quickly.

All flares in the same

The functions of the pi button:

1. The simple tap of the pi button will lock the side 12 LED lights flashing.
2. The 2nd tap of the pi button will lock the top 4 LED lights flashing.
3. The 3rd tap of the pi button will bring the flare back to its default state where the tilt sensor controls the choice of LEDs. When the flare is in the horizontal position (lying flat on the ground) the 12 side LEDs will illuminate. When the flare is in the vertical position (e.g. magnetically attached to the back of a truck tailgate) the 4 top LEDs will illuminate. The flare will automatically adjust the side which the LEDs flash according to the flare's orientation.
4. Press the pi button for 3 seconds and only turn off single flare but not the whole set.

WARNING

Do not look directly into LEDs while in operation; this may cause momentary blindness and/or eye damage.

strands[®]
-lighting division

ANVÄNDARINSTRUKTIONER

VARNINGSLJUS - SMART SANDWICH

FUNKTIONER

5 Flash patterns

Li-battery 703040

72 hours battery life

360 degree horizontal angle, 180 degree vertical angle

AC-adapter and cigg plug 12-24V DC

INSTRUKTIONER

Testa batteriets status genom att trycka på ON/OFF-knappen

Röd x 4 gånger = 75%>

Röd x 3 gånger = 50%>

Röd x 2 gånger = 25%>

Röd x 1 gång = Låg batterinivå. Laddning rekommenderas.

Tryck på ON/OFF-knappen för att byta blyxtmönster. En grön diod kommer att tala om för dig vilket mönster som är på.

Grön x1 = Mönster nr. 1, Grön x2 = Mönster nr.2 osv.

För att synkronisera/avsynkronisera · Tryck på ON/OFF-knappen två gånger snabbt.

Alla enheter kan stängas av samtidigt genom att hålla inne någon utav ON/OFF-knapparna i tre sekunder



pi π- knappens funktioner

1. Ett enkelt tryck på pi π- knappen kommer att låsa de 12 dioderna på sidan av enheten.
2. Två snabba tryck på pi π- knappen kommer att låsa de fyra dioderna på toppen.
3. Tre snabba tryck på pi π- knappen kommer att återställa enheten så att vinkeln på enheten bestämmer vilka dioder som lyser.
4. Håll inne pi π- knappen i tre sekunder för att stänga av enstaka enheter (inte hela setet).

VARNING

Kolla inte rakt in i blyxtljuset medan det är påslaget. Detta kan orsaka tillfällig blindhet och ögonskador.

strands[®]
-lighting division